

uvex

How to clean and store your uvex safety spectacles correctly



Cleaning under running water



Remove areas of rough dirt under running water.



Wipe the lenses clean using a dry paper towel from the uvex cleaning station.

Cleaning with the uvex cleaning station



Spray both sides of the lens with a generous amount of the cleaning solution.



Take a paper towel from the cleaning station.



Wipe the lenses clean using a dry towel.

Cleaning with uvex cleaning towelettes



Alternatively, uvex cleaning towelettes can be used to ensure optimal vision.



Clean both sides of the lens with the towelette. Repeat if necessary.

Storage



With case
Keep your uvex safety spectacles in a case.



Without case
DO NOT put your spectacles / goggles down on the nose bridge or lens.



protecting people

www.uvex-safety.com.au